


Part Number	Option
WHRF	Wheels and Handle Frame
WS2G	2 Gang Protection Module <ul style="list-style-type: none"> Vibration isolated IP66 weatherproof earth leakage/main circuit breaker
WS4G	WorkCover Spec 4 Gang Protection Module <ul style="list-style-type: none"> Vibration isolated combination IP66 weatherproof earth leakage / main circuit breaker and power outlets Removable roll frame centre lift bar Safety Operation Instructions
WS6G	WorkCover Spec 6 Gang Protection Module <ul style="list-style-type: none"> Vibration isolated combination IP66 weatherproof earth leakage/ main circuit breaker and individually switched power outlets. Removable roll frame centre lift bar
ESK	Earth Stake Kit - for use with Earth Leakage Circuit Breaker (ELCB)
CLB	Centre Lifting Bar (Removable)
18LFT	18 litre extended operation Fuel Tank (additional to existing fuel tank capacity)
50LFT	50 litre extended operation Fuel Tank
BF	Dry Battery fitted for electric start models
	Welding Cable Kits
WCK-5	5M Cables with HD 400A Electrode Holder and Earth Clamp
WCK-10	10M Cables with HD 400A Electrode Holder and Earth Clamp



Powerlite Generators

Proudly Australian Owned

Head Office & Manufacturing

2 Binney Road,

Kings Park NSW 2148

Phone: 02 9912 5000

Fax: 02 9912 5001

Email: sales@powerlite.com.au

Website: www.powerlite.com.au

Pick up your Powerlite Generator from: